



SCHOOL STYLE 21-PC DOUBLE LOCKER PLAYSET FOR 18" DOLLS - PURPLE

Assembly Instructions. Adult Assembly Required.

Read all instructions before use.

**This manual is part of the product and
must be kept for future reference.**



MODEL NUMBER*:
12026

VERSION CODE*:
1.0/0519/TG

** Model and Version numbers are
needed if replacement parts are requested*

Find us on  •  YouTube

FOR REPLACEMENT PARTS:
<http://www.badgerbasket.com/parts>

Badger Basket®, PO Box 227, Edgar, WI 54426-0227 USA • **Web:** www.badgerbasket.com
U.S. Based Customer Service Toll-Free (Mon-Thurs 7:00 AM-4:00 PM CST): 1-800-236-1310
Phone: 715-352-2311 • **Fax:** 715-352-3163



BEFORE YOU BEGIN ASSEMBLY:

Check all parts. If anything is missing or not satisfactory, please **DO NOT** call the store or return the product to them. Please go online to:

<http://www.badgerbasket.com/parts>

Most problems are resolved without you needing to leave home.

When emailing or calling us, please have this instruction manual, your product model number, and your Version Code ready.

Your Model Number is: 12026

Your Version Code is: 1.0/0519/TG

CARE INSTRUCTIONS:

Wipe the locker clean with a damp cloth and mild soap and dry thoroughly with a soft cloth. Spot clean accessories with cold water and mild detergent and dry with a cloth or allow to air dry.



WARNING

CHOKING HAZARD - SMALL PARTS. NOT FOR CHILDREN UNDER THREE (3) YEARS.



WARNING - CAUTION


READ ALL INSTRUCTIONS before use of this product. Use only the parts provided by Badger Basket®. Keep instructions for future use.

Do not use the product if it is damaged or broken. Periodically inspect the product to ensure all parts remain tight. **This item is a toy for dolls only. It is never to be used for real infants or pets. No product is a substitute for adult supervision. Always supervise your child during play.** For children ages three (3) years and older. Never sit on or stand on the toy. Never put a real infant or pet inside the locker.




ASSEMBLY TIP! Review the entire manual before beginning.


Four keys are included. We suggest that an adult keep one of the keys in a safe place.




LOCKER
A



HANGER
B×6




POCKET
ORGANIZER
C×2



MAGNETIC
MIRROR
D×2



MAGNETIC
BUTTERFLY
E×4



LOCK WITH
TWO KEYS
F×2

1

