

# Combo Bin Storage Unit with Three Baskets

Assembly Instructions. Adult Assembly Required.
Read all instructions before use.

This manual is part of the product and must be kept for future reference.



## **MODEL NUMBER\*:**

98864 - Gray Woodgrain 98865 - White w/Gray Top 98866 - Charcoal

# VERSION CODE\*: 1.2/1219/TG

\* Model and Version numbers are needed if replacement parts are requested


Find us on **ff** • **VouTube** • **©** 

Assembly Videos available on YouTube

#### **FOR REPLACEMENT PARTS:**

http://www.badgerbasket.com/parts

Badger Basket®, PO Box 227, Edgar, WI 54426-0227 USA • Web: www.badgerbasket.com U.S. Based Customer Service Toll-Free (Mon-Thurs 7:00 AM-4:00 PM CST): 1-800-236-1310 Phone: 715-352-2311 • Fax: 715-352-3163



#### **BEFORE YOU BEGIN ASSEMBLY:**

Check all parts. If anything is missing or not satisfactory, please DO NOT call the store or return the product to them. Please go online to:

http://www.badgerbasket.com/parts

Most problems are resolved without you needing to leave home.

When emailing or calling us, please have this instruction manual, your product model number, and your Version Code ready.

Your Model Number is: SEE COVER PAGE Your Version Code is: 1.2/1219/TG

#### **USE AND CARE INSTRUCTIONS:**

Wipe storage unit clean with a damp cloth and mild soap as needed. Dry thoroughly.

Do not use acidic cleaners (such as vinegar). Spot clean baskets as needed.

Do not immerse baskets in water. Some soft plastic/rubber toys (such as balls) can react with and cause damage to the finish when left in prolonged contact.

Be mindful of what is stored in the unit and regularly check toys and the unit to prevent damage.



### WARNING

ADULT ASSEMBLY REQUIRED
DUE TO THE PRESENCE OF SMALL PARTS AND SHARP
POINTS DURING ASSEMBLY, KEEP OUT OF REACH OF
CHILDREN UNTIL ASSEMBLY IS COMPLETE.



READ ALL INSTRUCTIONS before use of this product.

Keep instructions for future use. Use only the parts and hardware provided by Badger Basket®. Do not use the product if it is damaged, broken, or missing parts. DO NOT allow anyone to climb, sit on, stand on, or play on or inside of this product. It is not a seat, step stool, or ladder. Periodically check to make sure all the hardware remains tight. No product is a replacement for adult supervision.



**ASSEMBLY TIPS!** Review the entire manual before beginning. Leave hardware slightly loose during assembly and then go back and tighten fully at the end. If using a power screwdriver, keep torque setting low and go slow to prevent damage to the product.

LEFT SIDE A×1	BOTTOM B×1	BOTTOM DIVIDER C×2	BOTTOM FRONT D×1
BOTTOM BACK E×1	LOWER MIDDLE SHELF F×1	MIDDLE DIVIDER G×2	UPPER MIDDLE SHELF H×1
MIDDLE BACK I×1	TOP DIVIDER J×1	TOP BACK K×1	TOP L×1
TOP FRONT TRIM M×1	RIGHT SIDE N×1	PEG O×20	PLASTIC INSERT P×22
SMALL BASKET AND BOTTOM Q×2	LARGE BASKET AND BOTTOM R×1	98864-LIGHT GRAY OR 98865-WHITE LONG SCREW S×18	SMALL SCREW T×2
(4) 	<b>•</b>		
98864-BLACK OR 98865-LIGHT GRAY LONG SCREW U×4	TOOL REQUIRED (NOT INCLUDED)		

