

BENCH TOP TOY CHEST

Assembly Instructions. Adult Assembly Required.
Read all instructions before use.

This manual is part of the product and must be kept for future reference.



MODEL NUMBERS*:

01350 - Espresso 13511 - Gray 13512 - White

VERSION CODE*: 6.0/0419/TG

* Model and Version numbers are needed if replacement parts are requested

ASSEMBLY TIPS! Review the entire manual before beginning. Leave hardware slightly loose during assembly and then go back and tighten fully at the end. If using a power screwdriver, keep torque setting low and go slow to prevent damage to the product.

FOR REPLACEMENT PARTS: http://www.badgerbasket.com/parts

Badger Basket®, PO Box 227, Edgar, WI 54426-0227 USA • Web: www.badgerbasket.com
U.S. Based Customer Service Toll-Free (Mon-Thurs 7:00 AM-4:00 PM CST): 1-800-236-1310
Phone: 715-352-2311 • Fax: 715-352-3163

Find us on **F VouTube**



BEFORE YOU BEGIN ASSEMBLY:

Check all parts. If anything is missing or not satisfactory, please DO NOT call the store or return the product to them. Please go online to:

http://www.badgerbasket.com/parts

Most problems are resolved without you needing to leave home.

When emailing or calling us, please have this instruction manual, your product model number, and your Version Code ready.

Your Model Number is: SEE COVER PAGE
Your Version Code is: 6.0/0419/TG

USE AND CARE INSTRUCTIONS:

Wipe toy chest unit clean with a damp cloth and mild soap as needed. Dry thoroughly.

Do not use acidic cleaners (such as vinegar). Some soft plastic/rubber toys (such as balls)

can react with and cause damage to the finish when left in prolonged contact.

Be mindful of what is stored in the unit and regularly check toys and the unit to prevent damage.

WARNING

ADULT ASSEMBLY REQUIRED
DUE TO THE PRESENCE OF SMALL PARTS AND SHARP
POINTS DURING ASSEMBLY, KEEP OUT OF REACH OF
CHILDREN UNTIL ASSEMBLY IS COMPLETE.



READ ALL INSTRUCTIONS before use of this product. Keep instructions for future use. Use only the parts and hardware provided by Badger Basket®. Do not use the product if it is damaged, broken, or missing parts. DO NOT allow anyone to climb, stand on, or play on or inside of this product. It is not a step stool or ladder. Periodically check to make sure all the hardware remains tight. No product is a replacement for adult supervision.

SAFETY HINGE LID SUPPORTS MUST BE INSTALLED PROPERLY. If not installed or if installed improperly, the LID could free fall and slam shut unexpectedly causing serious injury. The SAFETY HINGE LID SUPPORTS have been installed properly if the LID remains open when unattended. No maintenance or lubrication of the SAFETY HINGE LID SUPPORTS is required. Bench top may be used as a seat for children weighing up to 100 pounds (45.5 kg).

6.0/0419/TG

A	В	С	D	Е	F	G	Н	I	J	TOOL NEEDED
						S*50mm	Buttute 4*14mm		B	•
1PC	1PC	1PC	1PC	1PC	1PC	8PCS	20PCS	2PCS	2PCS	NOT INCLUDED

A - LEFT

B-RIGHT

C - FRONT

D -BACK

E - BOTTOM


F - TOP


G - LARGE BOLT

H -SMALL SCREW

I - SAFETY HINGE

J - HINGE





THE TOP (PART F) WILL OPEN TO APPROXIMATELY THE ANGLE SHOWN HERE. DO NOT FORCE THE LID TO OPEN FURTHER THAN INTENDED OR IT MAY CAUSE DAMAGE TO THE TOY BOX AND HINGES.

